



Windows



- required system: Windows 10(1903) or above
- 1 – connect the controller to your Windows device via its USB cable
- 2 – wait till the controller is successfully recognized by your Windows to play, status LED becomes solid

Android



- required system: Android 9.0 or above
- OTG support is required on your Android device. Please contact your device manufacturer for more details
- 1 – hold B button, connect the controller to your Android device via its USB cable
- 2 – wait till the controller is successfully recognized by your Android to play, status LED becomes solid

Switch



- OTG cable is required for Switch Lite
- Switch system needs to be 3.0.0 or above
- go to System Setting > Controller and Sensors > Turn on [Pro Controller Wired Communication]
- NFC scanning, motion control, IR camera, HD rumble, notification LED are not supported, nor can the system be waken up
- 1 – connect the controller to your Switch dock via its USB cable
- 2 – wait till the controller is successfully recognized by your Switch to play, status LED becomes solid

Turbo function



- D-pad, Left stick, Right stick are not supported
- status LED blinks continuously when the button with turbo functionality is pressed
- hold the button you would like to set turbo functionality to and then press the star button to activate/deactivate its turbo functionality

连接 Windows 设备



- \* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。
- \* 将手柄连接到 Windows 设备的 USB 端口, 等待系统识别完成后, 状态指示灯常亮。

连接 Android 设备



- \* 要求 Android 设备系统版本为 9.0 或更高版本。
- \* 需要 Android 设备配备 USB 端口且支持 OTG 功能, 详情请咨询设备制造商。
- \* 按住 [ B ] 键不放并将手柄连接到 Android 设备的 USB 端口, 等待系统识别完成后, 状态指示灯常亮。

连接 Switch 主机



- \* Lite 机型需要使用 OTG 转接线。
- \* 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- \* 请确保 [设置] - [手柄与感应器] - [Pro 手柄的有线连接] 功能已开启。
- \* 不支持 NFC 扫描、六轴体感、红外摄像头、HD 振动、通知灯、唤醒主机等功能。
- \* 将手柄连接到 Switch 主机底座的 USB 端口, 等待系统识别完成后, 状态指示灯常亮。

连发功能



- \* 已开启连发功能的按键, 按下时状态指示灯会持续闪烁。
- \* 方向键、左 / 右摇杆不支持连发。
- \* 按住需要设置连发的功能键, 再按下 [星号键] 可开启 / 关闭按键连发。

Ultimate Software

- It gives you elite control over every piece of your controller: customize button mapping, adjust stick & trigger sensitivity, vibration control and create macros with any button combinations
- please visit [app.8bitdo.com](http://app.8bitdo.com) for the application

自定义配置

- \* 配置后可按下 配置键 切换不同的配置, 默认无配置。
- \* 请访问 [app.8bitdo.cn](http://app.8bitdo.cn) 获取精英软件使用, 可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度、宏等功能进行自定义配置。

Support



- Please visit [support.8bitdo.com](http://support.8bitdo.com) for further information & additional support



技术支持



- \* 请访问 [support.8bitdo.cn](http://support.8bitdo.cn) 了解详细信息。

